

SA-VE230

Hookup Raccordement

English

Make sure power to all components is turned off and disconnect the AC power cord before connecting the components.

Refer to the instructions supplied with each component.

Note

All striped wires should be connected to the minus (-) speaker terminals.

Tip

If you have an FM-AM receiver with a DIGITAL IN jack, in addition to a 5.1 channel analog connection, you can connect the DVD player using an optical or coaxial digital connecting cord (not supplied). You can enjoy higher quality sound by using these cords.

Français

Assurez-vous que tous les composants sont hors tension et débranchez le câble d'alimentation avant de raccorder les composants.

Reportez-vous aux instructions fournies avec chacun de composants.

Remarque

Tous les câbles rayés doivent être raccordés aux bornes négatives (-) des haut-parleurs.

Conseil

Si vous disposez d'un récepteur FM-AM doté d'une prise DIGITAL IN, en plus d'une connexion analogique 5.1 canaux, vous pouvez raccorder le lecteur DVD à l'aide d'un câble de connexion numérique optique ou coaxial (non fourni).

Vous pouvez exploiter un son de qualité supérieure en utilisant ces câbles.

